



Uninstalling Tricefy Uplink

Last Modified on 02/09/2017 2:06 pm EST

To remove Tricefy Uplink from a computer or server:

- 1) Download the uninstall executable: http://downloads.tricefy.com/tricefy_uplink/remove.exe
 - 2) Right click the downloaded executable and select **Run as Administrator** from the menu
-